

## MIR-AS-01Q

### IR Receiver Adapter

#### Manual




#### Features:

- Allows extension of an IR receiver without needing to splice the cable
- Quick-connect terminals for easy installation
- 1/8" (3.5mm) TRS Mini-plug connector
- Allows cables 20~26 AWG


#### Installation:

(Not to scale)



**NOTE:** The "Status" input on the IR connection block is not used when utilizing the IR Receiver Adapter.

#### Overview:



**WARRANTY:** This SECO-LARM product is warranted against defects in material and workmanship while used in normal service for one (1) year from the date of sale to the original customer.

**NOTICE:** The SECO-LARM policy is one of continual development and improvement. For that reason, SECO-LARM reserves the right to change specifications without notice. SECO-LARM is also not responsible for misprints. All trademarks are the property of SECO-LARM U.S.A., Inc. or their respective owners. Copyright © 2018 SECO-LARM U.S.A., Inc. All rights reserved.

**SECO-LARM® U.S.A., Inc.**

16842 Millikan Avenue, Irvine, CA 92606  
Phone: (949) 261-2999 | (800) 662-0800

Website: [www.seco-larm.com](http://www.seco-larm.com)  
Email: [sales@seco-larm.com](mailto:sales@seco-larm.com)

